












FIB-R-DOR & FIB-R-LITE EXISTING WALL FRAME INSTALLATION











<p>1</p> <p>ASSEMBLE FRAME PER DETAILS ON PAGE #1</p>	<p>2</p>  <p>SLIDE ASSEMBLED FRAME INTO EXISTING OPENING.</p>
<p>3</p>  <p>PLUMB AND LEVEL JAMB. SQUARE CORNERS. SLIDE PLASTIC SHIMS BETWEEN JAMB AND WALL UNTIL JAMB IS SNUG.</p>	<p>4</p>  <p>INSERT $\frac{3}{8}$" MASONRY BIT INTO HOLES PROVIDED IN FRAME. DRILL BLOCK WALL DEEP ENOUGH FOR 4" LONG ANCHOR SCREWS.</p>
<p>5</p>  <p>INSERT MASONRY SCREWS AND TIGHTEN UNTIL FRAME IS SECURE.</p>	<p>6</p>  <p>TRIM AWAY EXCESS SHIM WITH A SHARP WOOD CHISEL.</p>
<p>7</p>  <p>CAULK JOINT BETWEEN FRAME AND WALL WITH SILICONE SEALER.</p>	<p>8</p> <p>HANG DOOR AND INSTALL HARDWARE.</p>

FIB-R-DOR & FIB-R-LITE FRAME ASSEMBLY DETAILS

<p>1</p>  <p>LAY OUT HEADER AND JAMBS</p>	<p>2</p>  <p>SLIDE HEADER ONTO JAMBS UNTIL HOLES IN THE HEADER LINE UP WITH HOLES IN THE CONNECTION TABS.</p>
<p>3</p>  <p>INSERT STAINLESS STEEL SCREWS IN HOLES AND TIGHTEN SECURELY.</p>	<p>4</p>  <p>USE THIS METHOD OF FLOOR ANCHORING WHEN THRESHOLDS ARE REQUIRED.</p>
<p>5</p>  <p>USE THIS METHOD OF FLOOR ANCHORING WHEN THRESHOLDS AREN'T REQUIRED</p> <p>BASE ANCHOR</p>	<p>PROCEED TO APPROPRIATE INSTRUCTIONAL METHOD</p>

FIB-R-DOR & FIB-R-LITE

NEW CONSTRUCTION FRAME INSTALLATION

<p>1</p> <p>ASSEMBLE FRAME PER DETAILS ON PAGE #1</p>	<p>2</p>  <p>Locate Frame.</p>	<p>3</p>  <p>If no threshold is required place wood spreader bar at base. Length of spreader bar should be determined by matching inside dimension at header.</p>
<p>4</p>  <p>Fasten either base anchor or threshold to floor, whichever is required.</p>	<p>5</p>  <p>Support Frame.</p>	<p>6</p>  <p>Level Headers.</p>
<p>7</p>  <p>Plumb Jambs.</p>	<p>8</p>  <p>Square Corners.</p>	<p>9</p>  <p>Place and support wood spreader at center of frame.</p>
<p>10</p>  <p>Tee anchors required for masonry construction: (3) per jamb through 7'-6" high (4) per jamb through 7'-7" to 12'-0" high</p>	<p>11</p>  <p>Place tee anchor in jamb and wall, equally spaced, as wall is erected. Check frame during wall erection to keep frame plumb and square.</p>	<p>12</p> <p>Hang door and install hardware.</p>